

Instrument hang, gel, gobo and focus

College of Wooster 2010

“Mini Tech Olympics”

Beginning with a standard Source 4 instrument, teams will safely hang the instrument, gel the instrument, obtain and insert a predetermined gobo & focus the instrument. The 1st electric will be flown in and tied off safely for this event. (Only one team member “on stage” at a time.)

ACCOMPLISH THIS PROCESS IN THE FOLLOWING ORDER:

Beginning at HOME BASE get a Source-four lighting instrument and places it on floor at the hang position and then go to home base.

Hang the instrument correctly facing upstage. (Remember safety cable, shutters open).

Get labeling items to correctly label, circuit and hot-patch instrument leaving the light on.

Get gobo and holder and insert gobo into instrument. Sharp focus the instrument on the cyc according to the diagram below.

Get gel and frame and place in instrument.

Get donut and place in instrument and return to HOME BASE.

